

SOLOY AVIATION SOLUTIONS
CESSNA 206 WITH WING MOUNT CAMERA & DOWNLINK ANTENNA
NORMAL PROCEDURES REFERENCE CARD

Refer to Soloy Flight Manual Supplement for all operations. This document is provided as a pilot aid and does not supersede the FAA approved POHS.

APPROACHING AIRCRAFT

1. General Condition Check

INTERIOR CHECKS

1. Console Station Stowed and Secure
2. Sensor Controller Stowed and Secure
3. Sensor Monitors Stowed and Secure

FUSELAGE

1. Downlink Antenna Retracted and Secure

RIGHT WING

1. Verify Aileron Trim Tab Position..... 0° Without Camera Installed
9° Up Maximum With Camera Installed

LEFT WING

1. If Wing Camera is Installed:
 - a. Camera Size and Weight Check
 - b. Camera Mount Verify locked and safety wired.
 - c. Electrical Connections Verify all connections are tight and cable is secure.
2. If Wing Mounted Camera is Not Installed:
 - a. Access Cover Behind Dovetail Mount..... Verify correct cover is installed.
3. Verify Aileron Trim Tab Position..... 0° Without Camera Installed
9° Down Maximum With Camera Installed

NOTE

The trim tabs must be set equally from 0° to 9° dependant on the size of payload installed at the wing mount location.